


Software update

Connect the instrument to your computer, turn on and select *PC Communication* in the Main Menu. On the computer screen shows the contents of SD Card. Copy the file CXB_XXXX.CXP, supplied by MaintTech, to the PROGRAM folder in the instrument SD Card.




Turn off the instrument.

Now press the Esc/Back key  and  at the same time

and release the both keys.

Now you see this screen:



Select 1. *Load application from SD Card* and press ENTER.


A pop up window shows up with the existing program files. If there are several program files, you get a list and you select the latest file. Select the latest file and press ENTER.
If there is only one file, this will be selected automatically.

Now the file is stored in the RAM memory and it can run only until the instrument is turned off.

Note: Do not turn off the instrument!


You must store the file in the FLASH memory by doing the following:

Go to Main Menu and select 7. System and press ENTER.



The screen below shows up.

Select 1. Update program, press ENTER and the file will be stored in FLASH memory.



Now you have the latest software in the instrument.